




Honda CRF230 Rectifier/Regulator Instructions using RS CRF230 stator

- ❖ The stator is a straight replacement allowing to charge the battery and run an additional 80 watts of power.
- ❖ The 2 **YELLOW** wires from the RSCRF230 stator connect to the 2 **YELLOW** wires on the Rec/Reg (It does not matter which **YELLOW** wires from the Rec/Reg to **YELLOW** wires on stator)
- ❖ The **BLACK** from the Rec/Reg goes to the negative of battery
- ❖ The **RED** from the Rec/Reg goes to the positive of battery
- ❖ **NOTE:** in photo that Rec/Reg is mounted to top of air box with supplied self tapping screws.




Ricky Stator

1672 Main St., Ste. E, PMB 104, Ramona CA 92065
(760) 787-0094 • Fax 787-0313
E-mail: stator@adnc.com
www.rickystator.com



Honda CRF230 Rectifier/Regulator Instructions using RS CRF230 stator

- ❖ The stator is a straight replacement allowing to charge the battery and run an additional 80 watts of power.
- ❖ The 2 **YELLOW** wires from the RSCRF230 stator connect to the 2 **YELLOW** wires on the Rec/Reg (It does not matter which **YELLOW** wires from the Rec/Reg to **YELLOW** wires on stator)
- ❖ The **BLACK** from the Rec/Reg goes to the negative of battery
- ❖ The **RED** from the Rec/Reg goes to the positive of battery
- ❖ **NOTE:** in photo that Rec/Reg is mounted to top of air box with supplied self tapping screws.




Ricky Stator

1672 Main St., Ste. E, PMB 104, Ramona CA 92065
(760) 787-0094 • Fax 787-0313
E-mail: stator@adnc.com
www.rickystator.com



Honda CRF230 Rectifier/Regulator Instructions using RS CRF230 stator

- ❖ The stator is a straight replacement allowing to charge the battery and run an additional 80 watts of power.
- ❖ The 2 **YELLOW** wires from the RSCRF230 stator connect to the 2 **YELLOW** wires on the Rec/Reg (It does not matter which **YELLOW** wires from the Rec/Reg to **YELLOW** wires on stator)
- ❖ The **BLACK** from the Rec/Reg goes to the negative of battery
- ❖ The **RED** from the Rec/Reg goes to the positive of battery
- ❖ **NOTE:** in photo that Rec/Reg is mounted to top of air box with supplied self tapping screws.




Ricky Stator

1672 Main St., Ste. E, PMB 104, Ramona CA 92065
(760) 787-0094 • Fax 787-0313
E-mail: stator@adnc.com
www.rickystator.com



Honda CRF230 Rectifier/Regulator Instructions using RS CRF230 stator

- ❖ The stator is a straight replacement allowing to charge the battery and run an additional 80 watts of power.
- ❖ The 2 **YELLOW** wires from the RSCRF230 stator connect to the 2 **YELLOW** wires on the Rec/Reg (It does not matter which **YELLOW** wires from the Rec/Reg to **YELLOW** wires on stator)
- ❖ The **BLACK** from the Rec/Reg goes to the negative of battery
- ❖ The **RED** from the Rec/Reg goes to the positive of battery
- ❖ **NOTE:** in photo that Rec/Reg is mounted to top of air box with supplied self tapping screws.



Ricky Stator

1672 Main St., Ste. E, PMB 104, Ramona CA 92065
(760) 787-0094 • Fax 787-0313
E-mail: stator@adnc.com
www.rickystator.com